



1	GETTING STARTED
1.1	Press On . A brief message is displayed (such as <i>HELLO</i>). The scale then enters the gross weighing mode.
2	TO ZERO BALANCE THE SCALE (only with empty machine)
2.1	Press Net/Gross and then, immediately press Zero . <i>ZERO</i> is displayed briefly to show that the zero balance has been set. If <i>0</i> appears, the zero has been correctly set. If not, repeat procedure.
3	TO CHANGE THE LANGUAGE
3.1	Enter 101 using the numerical keypad.
3.2	Press Select . The current language appears on the display.
3.3	Press Select until the required language is displayed.
3.4	Press On to confirm the selected language.
4	TO CHANGE THE ENTRY METHOD
4.1	Enter 441 using the numerical keypad
4.2	Press Select . <i>E-MTHD</i> is displayed followed by the number 1, 2 or 3 (1: Amount per Animal in [kg], 2: Percent [%] per Load, 3: Amount per Load in [kg])
4.3	Press Select until the required entry mode is displayed.
4.4	Press On to confirm the selected entry mode.
5	TO CHANGE THE TOLERANCE (ALARM)
5.1	Enter 442 using the numerical keypad
5.2	Press Select . <i>TOLER...</i> is displayed and a value between 0,5% and 10%, or <i>OFF</i> .
5.3	Press Select until required value (e.g. 5%) is displayed.
5.4	Press On to confirm the selected setting.
6	TO RENAME INGREDIENTS
6.1	Press and hold Ingr/Accum and then press On . The scale displays <i>PROGRM</i> , followed by the first ingredient: <i>INGR 01</i> .
6.2	Press Ingr/Accum until the required ingredient number is displayed. If the display already shows the correct number, proceed with step 6.3.
6.3	Press On . The ingredient name concerned is displayed.
6.4	Press Clear to delete the name gradually or press and hold Clear to delete the entire name.
6.5	Enter a new ingredient name (max. 6 digits) using the numerical keypad. Each key contains 4 different characters.
6.6	Press On to confirm the new name. The following ingredient number will appear on the display.
6.7	Repeat steps 6.2 thru 6.6 until the required changes have been made.
6.8	Press Net/Gross to return to the normal weighing mode.
7	TO PROGRAM A NEW RECIPE
	 First select the required entry method (steps 4.1 thru 4.4)
7.1	Press and hold Recipe and then press On . The scale displays <i>PROGRM</i> , followed by the first recipe: <i>REC 01</i> , or <i>REC- _ _</i> if you have not programmed any recipes.
7.2	Press Recipe until <i>REC- _ _</i> is displayed.
7.3	Enter the required recipe number (e.g. <i>01</i>) using the numerical keypad.
7.4	Press Recipe to confirm the entered recipe number. A running text shows the chosen entry method. Then <i>INGR- _ _</i> is displayed.
7.5	Enter the required ingredient number (e.g. <i>01</i>) using the numerical keypad.
7.6	Press Ingr/Accum . The entered ingredient number with name is briefly displayed, followed by e.g. <i>01: _ _ .00</i> ; the first number is the recipe number.
7.7	Enter the required ingredient amount using the numerical keypad.
7.8	Press Load/Unload to confirm this amount. The scale will then display <i>LOADED</i> to indicate that the ingredient has been saved in the weigher's permanent memory, followed by <i>INGR- _ _</i> .
7.9	Repeat steps 7.5 thru 7.8 until all recipes have been entered.
7.10	Press Net/Gross to exit the recipe entry mode and enter weighing modes.
8	TO EDIT A RECIPE (only edit ingredient amount, do not add any ingredients!)
	 If you want to add ingredients, the recipe must be deleted (steps 9.1 thru 9.5)
8.1	Press and hold Recipe and then press On . The scale displays <i>PROGRM</i> .
8.2	Press Recipe until the recipe to be changed is displayed.
8.3	Press Ingr/Accum until the ingredient to be changed is displayed.
8.4	Press Clear to delete the amount and enter the new quantity using the numerical keypad.
8.5	Press Load/Unload to confirm this amount. The scale briefly displays <i>LOADED</i> .
8.6	Repeat steps 8.3 thru 8.5 until all ingredients are edited. The scale displays <i>TOTAL</i> directly followed by <i>REC- _ _</i> to edit another recipe.
8.7	Press Net/Gross to exit the recipe programming mode.

9	TO DELETE A RECIPE (completely delete a programmed recipe)
9.1	Press and hold Recipe and then press On . The scale displays <i>PROGRM</i> .
9.2	Press Recipe until the recipe to be deleted is displayed.
9.3	Press and hold Zero and then press On to delete this recipe. A running text with instructions shows that the old recipe can be printed.
9.4	Press Zero to delete this recipe. The scale displays <i>RECIPE ERASED</i> , followed by the next recipe.
9.5	Repeat steps 9.2 thru 9.4 until all recipes have been deleted.
9.6	Press Net/Gross to return to normal weighing mode.

10	TO LOAD A BATCH USING A RECIPE
10.1	Press Recipe until the required recipe number is displayed.
10.2	Press Load/Unload . The scale displays the number of animals or the programmed amount.
10.3	a) Press Load/Unload to confirm this number of animals and the programmed amount. b) To edit the number of animals or the amount, press Clear and enter the new values using the numerical keypad.
10.4	Press Load/Unload . The scale displays the calculated amount of the first ingredient.
10.5	Depending on the presetting the next ingredient will appear automatically or after Ingr/Accum has been pressed.
10.6	Once all ingredients have been loaded, the scale displays: <i>RECIPE COMPLETED TOTAL = XXX KG</i> .

11	TO REVIEW A RECIPE (to check a recipe)
11.1	Press Recipe . The scale displays the first recipe loaded in memory.
11.2	Press Recipe until the required recipe number is displayed.
11.3	Press Ingr/Accum . The scale displays all ingredients of the recipe. At the end it displays the totally programmed amount, <i>TOTAL = XXXX KG</i> .
11.4	Press Net/Gross to return to normal weighing mode.

12	TO REVIEW INGREDIENT ACCUMULATION
12.1	Press Ingr/Accum . The scale displays the first recipe and the total amount that has been dosed in since the last time this ingredient was deleted (see manual, page 30).
12.2	Press Ingr/Accum until all ingredients have been displayed.
12.3	Press Net/Gross to return to normal weighing mode.

For a more detailed description, see manual EZ 3200 / 3200V

1	Getting started	Page 8, 9
2	To zero balance the scale	Page 9
3	To change the language	- Press Net/Gross + On . - Press Select to select to menu 1 and press On . - Press Select until the required language is displayed: English / Nederl / Francs / Deutsh / Italian / Port / Espanl / Vesta / Magiar / Dansk. - Press On to confirm the selected language.
4	To change the entry method	Pages 18, 20 1 = Amount per Animal 2 = Percent % 3 = KG. Amount per Load
5	To change the tolerance	Page 24 (to change the tolerance) and page 25 (to change the delay time).
6	To rename ingredients	Pages 37, 29
7	To program a new recipe	Page 19 and for examples, pages 38, 39, 40.
8	To edit a recipe	Page 21
9	To delete a recipe	Page 22
10	To load a batch using a recipe	Pages 25, 26 Attention: (for Triomix Triomix s and Gigant set delay time to <i>MANUAL</i>) 1 Enter 443 using the numerical keypad. 2 Press Select . The scale displays <i>DELAY</i> followed by 5. 3 Press Select until <i>MANUAL</i> is displayed. 4 Press On to confirm the setting.
11	To review a recipe	Page 27
12	To review ingredient accumulation	Page 28