



EZ II Series Long-Form Set-Up Parameters

For Software Version EZII 1.G, 1.H

Table of Contents

StockWeigh 500 / EZ600	Page 1
EZ 2000, EZ2000V	Page 2
EZ 3200, EZ3200V	Page 4
EZ3500, EZ3500V	Page 6
EZ StockWeigh	Page 8
Keenan EZ3200, 3200V	Page 10
Chore-Time M100, M200	Page 12
Hesston Indicator	Page 14



EZ II Indicator Set-Up

StockWeigh 500 / EZ 600 Set-Up

Page 1

	EZ600 403530, 403531	StockWeigh 500 403416 403417 403418, 403419 403420, 403421
OPTIONS		
NUM AD	1	1
PRESET	off	off
RS-232	off	off
2M+VES	off	off
CLOCK	off	off
AD DSP	off	off
ID NO	off	off
HOLD	off	off
MEMORY	off	off
EZ500	ON	ON
BLKOUT	off	off
TMR MX	off	off
BATCHR	off	off
CTR MX	off	off
PCBTCH	off	off
SAVBAT	off	ON
FRONT PANEL OPTIONS		
L/UL	No Key	No Key
PRINT	No Key	No Key
ID NO	No Key	No Key
MEMORY	No Key	No Key
TIMER	No Key	No Key
BATCHER	No Key	No Key
PCBATCH	No Key	No Key
LONG FORM - SETUP/CALIBRATION SETTINGS		
LOCKON	8	8
LCKNHLD	ON	ON
ARANGE	off	ON
ZTRACK	off	ON
AUTOFF	off	30

EZ2000 Set-Up

	EZ 2000(V) 400590 (400591)	EZ 2000(V) W/REM 400590-01 (400591-01)	EZ 2000(V) W/SER 400590-02 (400591-02)	EZ 2000(V) W/REM/ SER 400590-03 (400591-03)	EZ 2000(V) W/TR 400590-04 (400591-04)	EZ 2000(V) W/TR 400590-05 (400591-05)
OPTIONS						
NUM AD	1	1	1	1	1	1
PRESET	off	off	off	off	off	off
RS-232	off	off	ON	ON	off	off
2M+VES	off	off	off	off	off	off
CLOCK	off	off	ON	ON	off	off
AD DSP	off	off	off	off	off	off
ID NO	off	off	off	off	off	off
HOLD	ON	ON	ON	ON	ON	ON
MEMORY	ON	ON	ON	ON	ON	ON
EZ500	off	off	off	off	off	off
BLKOUT	off	off	off	off	off	off
TMR MX	ON	ON	ON	ON	ON	ON
BATCHR	off	off	off	off	off	off
CTR MX	off	off	off	off	off	off
PCBTCH	off	off	off	off	off	off
SAVBAT	off	off	off	off	off	off
FRONT PANEL OPTIONS						
L/UL	No Key	No Key	No Key	No Key	No Key	No Key
PRINT	No Key	No Key	ON	ON	No Key	No Key
ID NO	No Key	No Key	No Key	No Key	No Key	No Key
MEMORY	off	off	off	off	off	off
MEMORY (V)	ON	ON	ON	ON	ON	ON
TIMER	off	off	off	off	off	off
BATCHR	No Key	No Key	No Key	No Key	No Key	No Key
PCBATCH	No Key	No Key	No Key	No Key	No Key	No Key
LONG FORM - SETUP/CALIBRATION SETTINGS						
MENU 1 - BASIC FEATURES (ALL SCALES)						
LANGAG	ENG	ENG	ENG	ENG	ENG	ENG
D RATE	2	2	2	2	2	2
MOTION	off	off	off	off	off	off
ZTRACK	off	off	off	off	off	off
M WTHD	1	1	1	1	1	1
LOCKON	8	8	8	8	8	8
TR HOLD	off	off	off	off	off	off
SCALID	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LCKNHLD	ON	ON	ON	ON	ON	ON
MENU 2 - CLOCK FEATURES						
TIME F			AM/PM	AM/PM		
TIME			SET	SET		
DATE F			7	7		
DATE			SET	SET		

EZ2000 Set-Up (cont.)

	EZ 2000(V) 400590 (400591)	EZ 2000(V) W/REM 400590-01 (400591-01)	EZ 2000(V) W/SER 400590-02 (400591-02)	EZ 2000(V) W/REM/ SER 400590-03 (400591-03)	EZ 2000(V) W/TR 400590-04 (400591-04)	EZ 2000(V) W/TR 400590-05 (400591-05)
MENU 2 - PRINT FEATURES						
TAREAP			SEE NOTE	SEE NOTE		
1L PRT			ON	ON		
SCOREM			0	0		
APRINT			off	off		
COM IN			DOWNLD	DOWNLD		
PRTFMT			AUTO	AUTO		
MEDIA	DDL	DDL	DDL	DDL	DDL	DDL
C1 DLY			.10	.10		
C2 DLY			off	off		
EST WT	0	0	0	0	0	0
MENU 3 - SCALE CALIBRATION SETTINGS						
COUNT	10	10	10	10	10	10
ARANGE	off	off	off	off	off	off
LB-KG	LB	LB	LB	LB	LB	LB
CAP	40000	40000	40000	40000	40000	40000
WMA1-1	10	10	10	10	10	10
WMA1-2	4	4	4	4	4	4
WMA1-3	4000	4000	4000	4000	4000	4000
WMA2-1	30	30	30	30	30	30
WMA2-2	10	10	10	10	10	10
WMA2-3	4000	4000	4000	4000	4000	4000
MENU 4 - PRESET FEATURES						
BUZZER	ON	ON	ON	ON	ON	ON
MENU 4 - AUTO-ERROR DETECTION FEATURES						
AERROR	ON	ON	ON	ON	ON	ON

NOTE: TAREAP IS "ON" EXCEPT FOR THE FOLLOWING GRAIN CART CUSTOMERS:

Altorfer	J&M	MacAllister	Parker	Sunflower
Bourgault	Kill Bros.	Orthman	Pixall	Unverferth
Bradford	Kinze	Oxbo	Richaldton	Ziegler

EZ3200 Set-Up

	EZ 3200(V) 400844 400845	EZ 3200(V) W/REM 400844-01 400845-01	EZ 3200(V) W/SER 400844-02 400845-02	EZ 3200(V) W/REM/ SER 400844-03 400845-03	EZ 3200(V) W/REM/ SER/REV 400844-13 400845-13
OPTIONS					
NUM AD	1	1	1	1	1
PRESET	ON	ON	ON	ON	ON
RS-232	off	off	ON	ON	ON
2M+VES	off	off	off	off	off
CLOCK	off	off	ON	ON	ON
AD DSP	off	off	off	off	off
ID NO	ON	ON	ON	ON	ON
HOLD	ON	ON	ON	ON	ON
MEMORY	ON	ON	ON	ON	ON
EZ500	off	off	off	off	off
BLKOUT	off	off	off	off	off
TMR MX	ON	ON	ON	ON	ON
BATCHR	ON	ON	ON	ON	ON
CTR MX	off	off	off	off	ON
PCBTCH	off	off	off	off	off
SAVBAT	off	off	off	off	off
FRONT PANEL OPTIONS					
L/UL	ON	ON	ON	ON	ON
PRINT	No Key	No Key	ON	ON	ON
ID NO	ON	ON	ON	ON	ON
MEMORY	off	off	off	off	off
TIMER	ON	ON	ON	ON	ON
BATCHR	ON	ON	ON	ON	ON
PCBATCH	No Key	No Key	No Key	No Key	No Key
LONG FORM - SETUP/CALIBRATION SETTINGS					
MENU 1 - BASIC FEATURES IN ALL SCALES					
LANGAG	ENG	ENG	ENG	ENG	ENG
D RATE	2	2	2	2	2
MOTION	off	off	off	off	off
ZTRACK	off	off	off	off	off
M WTHD	1	1	1	1	1
LOCKON	8	8	8	8	8
TR HOLD	off	off	off	off	off
SCALID	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LCKNHLD	ON	ON	ON	ON	ON
MENU 2 - CLOCK FEATURES					
TIME F			AM/PM	AM/PM	AM/PM
TIME			SET	SET	SET
DATE F			7	7	7
DATE			SET	SET	SET

EZ3200 Set-Up (cont.)

	EZ 3200(V)	EZ 3200(V) W/REM	EZ 3200(V) W/SER	EZ 3200(V) W/REM/ SER	EZ 3200(V) W/REM/ SER/REV
	400844	400844-01	400844-02	400844-03	400844-13
	400845	400845-01	400845-02	400845-03	400845-13
MENU 2 - PRINT FEATURES					
TAREAP			ON	ON	ON
1L PRT			ON	ON	ON
SCOREM			0	0	0
APRINT			off	off	off
COM IN			DOWNLD	DOWNLD	DOWNLD
PRTFMT			AUTO	AUTO	AUTO
MEDIA	DDL	DDL	DDL	DDL	DDL
C1 DLY			.10	.10	.10
C2 DLY			off	off	off
EST WT	0	0	0	0	0
MENU 3 - SCALE CALIBRATION SETTINGS					
COUNT	10	10	10	10	10
ARANGE	off	off	off	off	off
LB-KG	LB	LB	LB	LB	LB
CAP	40000	40000	40000	40000	40000
WMA1-1	10	10	10	10	10
WMA1-2	4	4	4	4	4
WMA1-3	4000	4000	4000	4000	4000
WMA2-1	30	30	30	30	30
WMA2-2	10	10	10	10	10
WMA2-3	4000	4000	4000	4000	4000
MENU 4 - PRESET FEATURES					
P MTHD	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P-ALM	100	100	100	100	100
RM INP	INGRED	INGRED	INGRED	INGRED	INGRED
AL OUT	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	ON	ON	ON	ON	ON
PRETAR	off	off	off	off	off
RELAY	ON	ON	ON	ON	ON
MENU 4 - MIX TIME/ROTATION COUNTER FEATURES					
TMRCTR					REV
DRATIO					1
MENU 4 - BATCHING FEATURES					
E MTHD	3	3	3	3	3
TOLER	off	off	off	off	off
DELAY	MANUAL	MANUAL	MANUAL	MANUAL	MANUAL
INGRNM	ON	ON	ON	ON	ON
ACCUM	ON	ON	ON	ON	ON
USERID	OFF	OFF	OFF	OFF	OFF
INGSIZ	OFF	OFF	OFF	OFF	OFF
RECTOT	LAST	LAST	LAST	LAST	LAST
SCOOP%			SEE NOTE	SEE NOTE	SEE NOTE
OVERLK	OFF	OFF	OFF	OFF	OFF
MENU 4 - AUTO-ERROR DETECTION FEATURES					
AERROR	off	off	off	off	off

NOTE: SCOOP% should be "ON" for TRIOLET ONLY.

Add Features PDL D02-26 7/16/02
 For Revision EZ2-1G ECR03-85 09/19/03
 For Revision EZ2-1H ECR04-008 04/19/04

EZ3500 Set-Up

	EZ3500(V) W/REM/ SER 403064-03 403065-03	EZ3500(V) W/REM/SER/REV 403064-13 403065-13	EZ3500(V) W/REM/KEY 403064-23 403065-23	EZ3500(V) W/REM/KEY/REV 403064-33 403065-33	EZ3500(V) W/REM/KEY/SER 403064-43 403065-43
OPTIONS					
NUM AD	1	1	1	1	1
PRESET	ON	ON	ON	ON	ON
RS-232	ON	ON	ON (per JB)	ON (per JB)	ON
2M+VES	off	off	off	off	off
CLOCK	ON	ON	ON	ON	ON
AD DSP	off	off	off	off	off
ID NO	ON	ON	ON	ON	ON
HOLD	ON	ON	ON	ON	ON
MEMORY	off	off	off	off	off
EZ500	off	off	off	off	off
BLKOUT	ON	ON	ON	ON	ON
TMR MX	ON	ON	ON	ON	ON
BATCHR	off	off	off	off	off
CTR MX	off	ON	off	ON	off
PCBTCH	ON	ON	ON	ON	ON
SAVBAT	off	off	off	off	off
FRONT PANEL OPTIONS					
L/UL	ON	ON	ON	ON	ON
PRINT	ON	ON	ON (per JB)	ON (per JB)	ON
ID NO	ON	ON	ON	ON	ON
MEMORY	No Key	No Key	No Key	No Key	No Key
TIMER	ON	ON	ON	ON	ON
BATCHR	No Key	No Key	No Key	No Key	No Key
PCBATCH	ON	ON	ON	ON	ON
LONG FORM - SETUP/CALIBRATION SETTINGS					
MENU 1 - BASIC FEATURES IN ALL SCALES					
LANGAG	ENG	ENG	ENG	ENG	ENG
D RATE	2	2	2	2	2
MOTION	off	off	off	off	off
ZTRACK	off	off	off	off	off
M WTHD	1	1	1	1	1
LOCKON	8	8	8	8	8
TR HOLD	off	off	off	off	off
SCALID	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LCKNHLD	ON	ON	ON	ON	ON
MENU 2 - CLOCK FEATURES					
TIME F	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	SET	SET	SET	SET	SET
DATE F	7	7	7	7	7
DATE	SET	SET	SET	SET	SET

EZ3500 Set-Up (cont)

	EZ3500(V) W/REM/ SER 403064-03 403065-03	EZ3500(V) W/RC/SER/REM 403064-13 403065-13	EZ3500(V) W/REM/KEY 403064-23 403065-23	EZ3500(V) W/REM/KEY/REV 403064-33 403065-33	EZ3500(V) W/REM/KEY/SER 403064-43 403065-43
MENU 2 - PRINT FEATURES					
TAREAP	off	off	off	off	off
1L PRT	off	off	off	off	off
SCOREM	0	0	0	0	0
APRINT	off	off	off	off	off
COM IN	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD
PRTFMT	AUTO	AUTO	AUTO	AUTO	AUTO
MEDIA	DDL	DDL	DATAKY	DATAKY	DATAKY
C1 DLY	.10	.10	.10	.10	.10
C2 DLY	off	off	off	off	off
EST WT	0	0	0	0	0
MENU 3 - SCALE CALIBRATION SETTINGS					
COUNT	10	10	10	10	10
ARANGE	off	off	off	off	off
LB-KG	LB	LB	LB	LB	LB
CAP	40000	40000	40000	40000	40000
WMA1-1	10	10	10	10	10
WMA1-2	4	4	4	4	4
WMA1-3	4000	4000	4000	4000	4000
WMA2-1	30	30	30	30	30
WMA2-2	10	10	10	10	10
WMA2-3	4000	4000	4000	4000	4000
MENU 4 - PRESET FEATURES					
P MTHD	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P-ALM	100	100	100	100	100
RM INP	INGRED	MIXCTR	INGRED	MIXCTR	INGRED
AL OUT	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	ON	ON	ON	ON	ON
PRETAR	off	off	off	off	off
RELAY	ON	ON	ON	ON	ON
MENU 4 - MIX TIME/ROTATION COUNTER FEATURES					
TMRCTR		REV		REV	
DRATIO		1		1	
MENU 4 - BATCHING FEATURES					
TOLER	off	off	off	off	off
DELAY	MANUAL	MANUAL	MANUAL	MANUAL	MANUAL
USERID	ON	ON	ON	ON	ON
MSTORE	AUTO	AUTO	QSTART	QSTART	QSTART
RESIZE	ON	ON	ON	ON	ON
OVERLK	off	off	off	off	off
MENU 4 - AUTO-ERROR DETECTION FEATURES					
AERROR	off	off	off	off	off

EZ StockWeigh Set-Up

	EZ STOCK WEIGH	EZ STOCK WEIGH
	403036	W/SER
	403084	403036-02
		403038
OPTIONS		
NUM AD	1	1
PRESET	off	off
RS-232	off	ON
2M+VES	off	off
CLOCK	off	ON
AD DSP	off	off
ID NO	off	off
HOLD	off	off
MEMORY	ON	ON
EZ500	off	off
BLKOUT	off	off
TMR MX	off	off
BATCHR	off	off
CTR MX	off	off
PCBTCH	off	off
SAVBAT	ON	ON
FRONT PANEL OPTIONS		
L/UL	No Key	No Key
PRINT	No Key	ON
ID NO	No Key	No Key
MEMORY	ON	ON
TIMER	No Key	No Key
BATCHR	No Key	No Key
PCBATCH	No Key	No Key
LONG FORM - SETUP/CALIBRATION SETTINGS		
MENU 1 - BASIC FEATURES IN ALL SCALES		
LANGAG	ENG	ENG
D RATE	2	2
MOTION	off	off
ZTRACK	ON	ON
M WTHD	1	1
LOCKON	8	8
TR HOLD	off	off
SCALID		
LCKNHLD	ON	ON
ARANGE		
AUTOFF	30	30
MENU 2 - CLOCK FEATURES		
TIME F		AM/PM
TIME		SET
DATE F		7
DATE		SET

EZ StockWeigh Set-Up (cont)

	EZ STOCK WEIGH	EZ STOCK WEIGH W/SER
	403036	403036-02
	403084	403038
MENU 2 - PRINT FEATURES		
TAREAP		ON
1L PRT		off
SCOREM		0
APRINT		off
COM IN		DOWNLD
PRTFMT		AUTO
MEDIA	DDL	DDL
C1 DLY		.10
C2 DLY		off
EST WT	0	0
MENU 3 - SCALE CALIBRATION SETTINGS		
COUNT	10	10
ARANGE	off	off
LB-KG	LB	LB
CAP	40000	40000
WMA1-1	10	10
WMA1-2	4	4
WMA1-3	4000	4000
WMA2-1	30	30
WMA2-2	10	10
WMA2-3	4000	4000
MENU 4 - PRESET FEATURES		
BUZZER		ON
MENU 4 - MIX TIME/ROTATION COUNTER FEATURES		
MENU 4 - BATCHING FEATURES		
MENU 4 - AUTO-ERROR DETECTION FEATURES		
AERROR	off	off

Keenan EZ3200 Set-Up

	EZ 3200(V) 403386 400846 400847	EZ 3200(V) W/REM 400846-01 400847-01	EZ 3200(V) W/SER 400846-02 400847-02	EZ 3200(V) W/REM /SER 400846-03 400847-03	EZ 3200(V) W/REM/ SER/REV 400846-13 400847-13
OPTIONS					
NUM AD	1	1	1	1	1
PRESET	ON	ON	ON	ON	ON
RS-232	off	off	ON	ON	ON
2M+VES	off	off	off	off	off
CLOCK	off	off	ON	ON	ON
AD DSP	off	off	off	off	off
ID NO	ON	ON	ON	ON	ON
HOLD	ON	ON	ON	ON	ON
MEMORY	ON	ON	ON	ON	ON
EZ500	off	off	off	off	off
BLKOUT	off	off	off	off	off
TMR MX	ON	ON	ON	ON	ON
BATCHR	ON	ON	ON	ON	ON
CTR MX	off	off	off	off	ON
PCBTCH	off	off	off	off	off
SAVBAT	off	off	off	off	off
FRONT PANEL OPTIONS					
L/UL	ON	ON	ON	ON	ON
PRINT	No Key	No Key	ON	ON	ON
ID NO	ON	ON	ON	ON	ON
MEMORY	off	off	off	off	off
TIMER	ON	ON	ON	ON	ON
BATCHR	ON	ON	ON	ON	ON
PCBATCH	No Key	No Key	No Key	No Key	No Key
LONG FORM - SETUP/CALIBRATION SETTINGS					
MENU 1 - BASIC FEATURES IN ALL SCALES					
LANGAG	ENG	ENG	ENG	ENG	ENG
D RATE	2	2	2	2	2
MOTION	off	off	off	off	off
ZTRACK	off	off	off	off	off
M WTHD	1	1	1	1	1
LOCKON	8	8	8	8	8
TR HOLD	off	off	off	off	off
SCALID					
LCKNHLD	ON	ON	ON	ON	ON
MENU 2 - CLOCK FEATURES					
TIME F			AM/PM	AM/PM	AM/PM
TIME			SET	SET	SET
DATE F			7	7	7
DATE			SET	SET	SET

Keenan EZ3200 Set-Up (cont.)

	EZ 3200(V) 403386 400846 400847	EZ 3200(V) W/REM 400846-01 400847-01	EZ 3200(V) W/SER 400846-02 400847-02	EZ 3200(V) W/REM /SER 400846-03 400847-03	EZ 3200(V) W/REM/ SER/REV 400846-13 400847-13
MENU 2 - PRINT FEATURES					
TAREAP			ON	ON	ON
1L PRT			ON	ON	ON
SCOREM			0	0	0
APRINT			off	off	off
COM IN			DOWNLD	DOWNLD	DOWNLD
PRTFMT			AUTO	AUTO	AUTO
MEDIA	DDL	DDL	DDL	DDL	DDL
C1 DLY			.10	.10	.10
C2 DLY			off	off	off
EST WT	0	0	0	0	0
MENU 3 - SCALE CALIBRATION SETTINGS					
COUNT	10	10	10	10	10
ARANGE	off	off	off	off	off
LB-KG	LB	LB	LB	LB	LB
CAP	40000	40000	40000	40000	40000
WMA1-1	10	10	10	10	10
WMA1-2	4	4	4	4	4
WMA1-3	4000	4000	4000	4000	4000
WMA2-1	30	30	30	30	30
WMA2-2	10	10	10	10	10
WMA2-3	4000	4000	4000	4000	4000
MENU 4 - PRESET FEATURES					
P MTHD	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P-ALM	50	50	50	50	50
RM INP	INGRED	INGRED	INGRED	INGRED	INGRED
AL OUT	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	ON	ON	ON	ON	ON
PRETAR	off	off	off	off	off
RELAY	ON	ON	ON	ON	ON
MENU 4 - MIX TIME/ROTATION COUNTER FEATURES					
TMRCTR					REV
DRATIO					1
MENU 4 - BATCHING FEATURES					
E MTHD	3	3	3	3	3
TOLER	off	off	off	off	off
DELAY	MANUAL	MANUAL	MANUAL	MANUAL	MANUAL
INGRNM	ON	ON	ON	ON	ON
ACCUM	ON	ON	ON	ON	ON
USERID	OFF	OFF	OFF	OFF	OFF
ING SIZ	OFF	OFF	OFF	OFF	OFF
RECTOT	LAST	LAST	LAST	LAST	LAST
SCOOP%			OFF	OFF	OFF
OVERLK	OFF	OFF	OFF	OFF	OFF
MENU 4 - AUTO-ERROR DETECTION FEATURES					
AERROR	off	off	off	off	off

Chore-Time Set-Up

	Chore-Time M100 47590 AUTO ON	Chore-Time M200 47595 AUTO ON
OPTIONS		
NUM AD	1	1
PRESET	off	ON
RS-232	ON	ON
2M+VES	off	off
CLOCK	off	ON
AD DSP	off	off
ID NO	off	off
HOLD	off	off
MEMORY	off	off
EZ500	off	off
BLKOUT	off	ON
TMR MX	off	off
BATCHR	off	off
CTR MX	off	off
PCBTCH	off	off
SAVBAT	off	off
FRONT PANEL OPTIONS		
L/UL	No Key	ON
PRINT	off	off
ID NO	No Key	No Key
MEMORY	No Key	No Key
TIMER	No Key	No Key
BATCHR	No Key	No Key
PCBATCH	No Key	No Key
LONG FORM - SETUP/CALIBRATION SETTINGS		
MENU 1 - BASIC FEATURES IN ALL SCALES		
LANGAG	ENG	ENG
D RATE	2	2
MOTION	off	off
ZTRACK	off	off
M WTHD	1	1
LOCKON	8	8
TR HOLD	off	off
SCALID	NEW EZ	NEW EZ
LCKNHLD	off	off
MENU 2 - CLOCK FEATURES		
TIME F		AM/PM
TIME		SET
DATE F		7
DATE		SET

Chore-Time Set-Up (cont)

	Chore-Time M100 47590 AUTO ON	Chore-Time M200 47595 AUTO ON
MENU 2 - PRINT FEATURES		
TAREAP	ON	ON
1L PRT	ON	ON
SCOREM	3	3
APRINT	off	off
COM IN	EZCMD	EZCMD
PRTFMT	AUTO	AUTO
MEDIA	DDL	DDL
C1 DLY	.10	.10
C2 DLY	off	off
EST WT	0	0
MENU 3 - SCALE CALIBRATION SETTINGS		
COUNT	10	10
ARANGE	off	off
LB-KG	LB	LB
CAP	40000	40000
WMA1-1	10	10
WMA1-2	4	4
WMA1-3	4000	4000
WMA2-1	30	30
WMA2-2	10	10
WMA2-3	4000	4000
MENU 4 - PRESET FEATURES		
P MTHD		WEIGHT
P-ALM		0
RM INP		PRESET
AL OUT		PRESET
BUZZER		off
PRETAR		off
RELAY		ON
MENU 4 - MIX TIME/ROTATION COUNTER FEATURES		
MENU 4 - BATCHING FEATURES		
MENU 4 - AUTO-ERROR DETECTION FEATURES		
AERROR	off	off

Hesston Set-Up

Hesston	
	403059
	AUTO ON
OPTIONS	
NUM AD	1
PRESET	off
RS-232	ON
2M+VES	off
CLOCK	off
AD DSP	off
ID NO	off
HOLD	off
MEMORY	off
EZ500	off
BLKOUT	off
TMR MX	off
BATCHR	off
CTR MX	off
PCBTCH	off
SAVBAT	off
FRONT PANEL OPTIONS	
L/UL	No Key
PRINT	ON
ID NO	No Key
MEMORY	No Key
TIMER	No Key
BATCHR	No Key
PCBATCH	No Key
LONG FORM - SETUP/CALIBRATION SETTINGS	
MENU 1 - BASIC FEATURES IN ALL SCALES	
LANGAG	ENG
D RATE	2
MOTION	off
ZTRACK	ON
M WTHD	1
LOCKON	8
TR HOLD	off
SCALID	NEW EZ
LCKNHLD	off
MENU 2 - CLOCK FEATURES	

Hesston Set-Up (cont)

Hesston	
	403059
	AUTO ON
MENU 2 - PRINT FEATURES	
TAREAP	ON
1L PRT	ON
SCOREM	3
APRINT	off
COM IN	EZCMD
PRTFMT	WTONLY
MEDIA	DDL
C1 DLY	.10
C2 DLY	off
EST WT	0
MENU 3 - SCALE CALIBRATION SETTINGS	
COUNT	10
ARANGE	off
LB-KG	LB
CAP	40000
WMA1-1	10
WMA1-2	4
WMA1-3	4000
WMA2-1	30
WMA2-2	10
WMA2-3	4000
MENU 4 - PRESET FEATURES	
BUZZER	
MENU 4 - MIX TIME/ROTATION COUNTER FEATURES	
MENU 4 - BATCHING FEATURES	
MENU 4 - AUTO-ERROR DETECTION FEATURES	
AERROR	off